

Wireless panic button

Code: JA-188J

The RC-188J is mainly used as a wireless panic or emergency button. It is designed to be a remote control for setting/unsetting an alarm system or remotely controlling other appliances.



Product description:

It provides **tamper contacts** and **monitors the voltage** of its battery.

The system **reaction to button activation is optional**. The basic reaction is a panic alarm or setting/unsetting the system (selectable).

Other reactions can be chosen in control panel service mode.

Technical information:

| | |
|---|---|
| Voltage | Lithium battery type CR14250 (1/2 AA) 3.6V/1.2 Ah Please note: Battery is not included |
| Typical battery lifetime | approximately 3 years (20 daily activations) |
| Communication band | 868.1 MHz, Jablotron protocol |
| Communication range | approx. 300 metres (open area) |
| Dimensions, weight | 80 x 80 x 29 mm, 60 g |
| Operational environment according to | EN 50131-1 class II. Indoor general |
| Operational temperature range | -10 °C to + 40 °C |
| Complies with EN 50131-1, EN 50131-5-3, EN 50134-2 | grade 2 |
| Complies with | ETSI EN 300220, EN 50130-4, EN 55022, EN 60950-1 |
| Can be operated according to | ERC REC 70-03 |